

SLIDEBEL DUO

Automatic Slide labelling

Slidebel Duo Tools 1.0.5

Order No: SBD-TOOLS

© 2021 All rights reserved Version 1.0.5

Read carefully before working with the instrument

About this manual

The information contained in this manual is the product of a number of internal tests, customer comments and the current state of scientific and technological knowledge.

GordiamKey has no obligation to periodically update the information contained in this manual.

GordiamKey does not accept any liability for any erroneous statement, illustration or picture contained in this manual. Furthermore, GordiamKey does not accept any liability, in terms of financial loss or damage to persons or things, caused by or related to the information contained in this manual.

All the information contained in this manual is intended only as a guide for

correct operation and to prevent risk to users. However, all users should first use their own common sense and judgement to avoid risk to persons or things.

GordiamKey reserves the right to change technical specifications as well manufacturing processes without notice. This document is protected under copyright law. All copyrights to this documentation are held by GordiamKey. reproduction Anv of text illustrations (or of any parts thereof) by means of print, photocopy or other methods - including any electronic systems and media – requires express permission prior in writing bv GordiamKey.

© GordiamKey



Contact details of the manufacturer

In case of assistance, contact an authorised distributor.

GordiamKey, Medeon Science Park, 205 12 Malmö, Sweden info@gordiamkey.com

1. Introduction	3
2. Printing form	4
2.1 Preview form	4
2.2 Enumerators and number of copies	5
2.3 Default Printer selection	6
2.4 Scanner mode	7
2.5 Protocols Panel	8
3. Label Layout editor panel	9
3.1 Field management panel	9
3.2 Layout management panel	10
3.3 Label preview	10
3.4 Field panel	11
3.5 Edit a Text field	11
3.5.1 Prompt Text	13
3.5.2 Static Text	14
3.5.3 Text List	15
3.5.4 Date	16
3.5.5 Number range	17
3.5.6 Incrementing letter	18
3.5.7 Concatenate text	19
3.6 Edit a code field	20
3.6.1 Datamatrix	21
3.6.2 QR code	22
3.6.3 Code 128	23
3.6.4 ITF 25:	24
3.7 Scanner	25
4 Protocols nanel	28

1. Introduction


1. Introduction

Slidebel Duo Tools is a free software tool for the Slidebel Duo printer. It can be used to customize label formats and to print slides. It also allows the user to change some printer settings. Slidebel Duo Tools is divided into 3 main panels:

- 1. Printing panel
- 2. Label layout editor panel
- 3. Printer settings panel

2. Printing form

The Printing form allows to print slides based on the selected label layout.




2.1 Preview form

The preview form will update as information is entered in the layout fields.

Same fields are static or automatically generated and do not require any input. The label layout, the number and type of fields in the layout can be modified from the *Label Layout* edit panel

In the example below, once the staining code is selected, it will appear in the print form.




2.2 Enumerators and number of copies

If an enumerator field is present in the label layout, it can be activated by pressing the appropriate checkbox. The program will issue a corresponding number of slides.



When the checkbox next to an enumeration field is selected, the number of copies in the print button area disappear. The program automatically prints all the possible combinations of slides.




The example above will issue two slides:






2.3 Default Printer selection

The default printer can be selected from a list of installed printers by pressing the button *"Select Printer"*



2.4 Scanner mode

If scanner mode is enabled, the Printing Panel will show the options "*Scanner autofill*" and the checkbox "*Scan and print*". After scanning a 1D or 2D code, the fields will be automatically filled as shown in the picture. To automatically print the label after the scan, the checkbox "*Scan and print*" must be activated.




2.5 Protocols Panel

The tab "*Protocols*" can be accessed to print a number of slides according to a specific printing protocol. This panel will only be visible if at least one printing protocol is present. To create, modify, and remove existing printing protocols, visit the "*Edit protocols*" panel, further information on this topic can be found in section 4 Protocols panel.




In the "*Protocols*" tab, select the desired protocol and fill in the printing fields or use the automatic scanner option.



3. Label Layout editor panel

The Label Layout editor panel allows to create and edit the label layout.



3.1 Field management panel



"Add" allows the user to add a field in the layout. The field type can be selected in the selection box.

The field can be a *Text*, which contains a string of letters or numbers, or a *Code*, like a barcode or a 2D code.



A maximum of 9 fields can be added in a single layout. A maximum of 2 fields of *Code* type may be used.

3.2 Layout management panel


The buttons *Load*, *Save*, and *Default* are used to manage the label layout files in the application.



- "Load": allows the user to load a previously saved layout. Only files with ".slbl" extension can be opened. This will also load any protocol list associated with the layout.
- "Save": allows the user to save the current layout. A file with ".slbl" extension will be created. This will also save any protocol list associated with the layout.
- "Save as default": allows the user to set the current layout as default in the printing panel, and use it to print slides.


3.3 Label preview

The Label preview panel displays the current label layout:



3.4 Field panel


The Field panel is used to edit or remove the label layout fields.



3.5 Edit a Text field

Once a Text field has been added, it can be edited in the Edit panel, by pressing the button

The selected text field being edited will be highlighted in the Label preview panel.



Edit panel

There are different types of text field:


- *Static text*: fixed text, not editable in the Printing panel
- **Prompt text**: editable text in the Printing panel
- Text list: text list presented in a combo box in the Printing panel

3. Label Layout editor panel

- *Date*: text containing the current system date
- *Number range*: text containing a number, automatically incrementing with the number of slides printed
- *Incrementing letter*: text containing a letter, automatically incrementing with the number of slides printed
- *Concatenate text*: text containing other elements, divided by a separator


3.5.1 Prompt Text

- *Label Name*: the field's name, as shown in the Printing panel
- *Display Text*: the suggested text, as shown in the Printing panel
- *X position*: the horizontal position of the field
- *Y position*: the vertical position of the field
- Font Size: the text's font size
- *Rotation*: the angle of pattern rotation of the text
- *Hide*: if selected, the field will not be printed




3.5.2 Static Text

- *Label Name*: the field's name. This will not be visible in the printing panel
- *Display Text*: the string that will be printed
- *X position*: the horizontal position of the field
- *Y position*: the vertical position of the field
- Font Size: the text's font size
- *Rotation*: the angle of pattern rotation of the text
- *Hide:* if selected, the field will not be printed




3.5.3 Text List

- *Label Name*: the field's name, as shown in the Printing panel
- *X position*: the horizontal position of the field
- *Y position*: the vertical position of the field
- Font Size: the text's font size
- *Rotation*: the angle of pattern rotation of the text
- *Hide:* if selected, the field will not be printed
- *List:* the list of selectable strings of the text field




3.5.4 Date

- *Label Name*: the field's name. This will not be visible in the printing panel
- *X position*: the horizontal position of the field
- *Y position*: the vertical position of the field
- Font Size: the text's font size
- *Rotation*: the angle of pattern rotation of the text
- *Hide:* if selected, the field will not be printed
- Date format: the desired date format



3.5.5 Number range

- *Label Name*: the field's name, as shown in the Printing panel
- *X position*: the horizontal position of the field
- *Y position*: the vertical position of the field
- Font Size: the text's font size
- *Rotation*: the angle of pattern rotation of the text
- *Hide:* if selected, the field will not be printed
- Zero-padding: if selected, the number will be zero-padded



3.5.6 Incrementing letter

• Label Name: the field's name, as shown in the Printing panel


• *X position*: the horizontal position of the field

• *Y position*: the vertical position of the field

• Font Size: the text's font size


• Rotation: the angle of pattern rotation of the text

• *Hide*: if selected, the text will not be printed



3.5.7 Concatenate text

- *Label Name*: the field's name, as shown in the Printing panel
- *X position*: the horizontal position of the field
- *Y position*: the vertical position of the field
- Font Size: the text's font size
- *Rotation*: the angle of pattern rotation of the text
- *Hide*: if selected, the text will not be printed
- List: the list of strings which will be concatenated in the text field




3.6 Edit a code field

Once a Code field has been added, it can be edited in the Edit panel, by pressing the button

Codes contain data originating from the text fields, by means of prompt insertion, static texts and separators.

Four different types of codes can be used:

- Code 128
- Datamatrix
- QR Code
- ITF 25




- *Label Name*: The field's name, visible in the Edit panel
- *Type*: The type of the code
- *X position*: the horizontal position of the field
- *Y position*: the vertical position of the field
- *Comp:* The compression factor, only for Datamatrix and QR-code
- Y Size: The compression factor, only for Code 128 and ITF 25
- *ID list:* the IDs of the fields which will be concatenated in the code value
- *Value List*: the list of string which will be concatenated in the code value

3.6.1 Datamatrix







List




Print preview

3.6.2 QR code






List




Print preview


3.6.3 Code 128



List



3.6.4 ITF 25:








3.7 Scanner


A barcode or 2D code scanner can be used in keyboard emulation mode to enable automatic filling of the label fields.

The process requires a specific formed input string, encoded into the barcode or 2D code. The string must be divided in several portions by a separator character, such as a comma (,) a dash (-) or another character (-). The scanner must be connected to the system running Slidebel Tools. Upon a successful reading, the input string will be split into different substrings and each of these will be addressed to the specific label fields.


In the example below, the datamatrix code contains the string "New York-23849-Jack Doe"




In the label layout below, "New York" must fill the field "lab", "23849" must fill the field "code", and "jack Doe must fill the field "operator".




To activate the scanner mode, click the button "*Scanner Options*":




A dialog box will open. The different substrings must be assigned to the appropriate label fields. A separator character must also be selected.



In this case, the separator is a dash (-) character. The first field will be set as "*lab*", the second as "*code*" and the third as "*operator*". A preview of the scanned code will be shown in the bottom of the window. Once all the fields are selected, click the button "enable" to activate the scanner mode.




The scanner status label will toggle to "ON":




4 Protocols panel

The Edit protocols panel allows to create, modify and remove slide printing protocols.

A slide printing protocol is a list of slides to be printed, whose fields are partially or totally pre-defined. Printing protocols can be created in the tab "*Edit protocols*" by clicking the button "*Add New*". This will generate a new protocol.




The "*Select editable fields*" option indicates which fields will be defined in the slide list. The rest of the fields will be open for edit in the printing form.



For each slide in the list, the loading side can be specified in the tab "Cartridge"

4. Protocols panel



Once completed, the protocol can be saved. Saved printing protocols can be used in the printing form.



www.gordiamkey.com